




MANOIR MARIE

ARTISANALE VLOEREN

OLD BLUE 'WAALTJES'

TECHNICAL DATA

22cm long x 4.2cm wide x 2.5-3cm thick [8.66 x 1.65 x 1-1.2 in]
ca 105 pcs/m² with joint width of 1 mm [0.04 in] (almost touching)



New Life

This is an old recycled handmade product: the size of the 'Waaltes' may differ slightly. The colour nuance may also differ slightly from batch to batch.



For interior use and covered terraces.

This is an old recycled product: please order in time since the old recycled floor tiles are becoming scarce

INSTALLING INSTRUCTIONS

- It is of major importance that the 'Waaltes' are well mixed.
- The 'Waaltes' are always laid in irregular bond. That means that entire, half and three-quarter 'Waaltes' are being laid at random to one's own taste.
- We recommend to keep a joint width of 1 (to 2) mm. The 'Waaltes' are handmade, may differ slightly in size and a good installation will require just a little more attention and time. The laying in irregular bond of the 'Waaltes' will help to keep the prescribed joint width. This procedure allows to obtain the most authentic outcome with an appearance of the olden days.
- Wet the 'Waaltes' briefly before installation so that mortar/glue cannot dry too quickly.
- To be laid in grey mortar bed or in a thick glue of 1cm.
- It's appropriate to double-glue the tiles, this means put glue on both the tile and the underground.
- Joint colour: silvergrey or old white. In case of doubt, you may ask the floor layer to perform a sample before jointing the whole surface.
- The joint can always be 1 mm deeper than the 'Waaltes', so not level with them. This will keep the shape of the 'Waaltes' visible whereas the joint remains less apparent.

- Before starting the jointing work, wet the floor abundantly. Joint small surfaces at once and sweep them off regularly. The 'Waaltes' are very susceptible to cement grout film and must be cleaned correctly.
- When the tiles are completely dried out, clean the entire surface (with cement remover when necessary) until all traces of cement are removed. When the floor is fully dry again, please treat the surface with the impregnation product "Remmers Funcosil AG impregnering" or "Lithofin Cotto Pre Wax". Apply the product twice with a soft painting roller, wet on wet. The product can foam slightly while you are applying it. After treating the whole floor, please polish it with a clean cotton cloth until all stripes have disappeared. Please only walk over the floor after 24 hours.
- Weekly maintenance with a vacuum cleaner and a nourishing soap (Berdy Topbril or Lithofin Wash & Clean) afterwards.
- Enjoy the beautiful result now!