



MANOIR MARIE

ARTISANALE VLOEREN

## HANDICRAFT DINANT BLUE

### TECHNICAL DATA

28 x 28cm x 2cm thick (approx. 12.5 pieces/m<sup>2</sup>)  
with joint thickness 2mm (as close together as possible)

This is a new handmade natural product and therefore the color and size of the tiles may vary slightly within 1 particular lot and between different production lots.



For interior and exterior use.

*This is a new unique handmade product that can only be manufactured in small volumes:  
please order in time!*

### INSTALLING INSTRUCTIONS

- It is very important that the tiles be mixed nicely.
- The tiles are usually placed in a half-stone bond.
- We recommend a joint width of 2 mm. The tiles are handmade, may vary slightly in size and therefore proper placement requires just a little more time and attention
- To be placed in gray cement or glued with 3-4 mm glue.
- The tiles are best double glued, this means both the tile and the screed (substrate) with glue.
- Joint color: silver grey (20L of dune sand - 10L of white sand - 10L of white cement - 1L of Classic gray Holcim) or old white (15L white sand - 15 L dune sand - 10L white cement - 0.5L gray hydraulic lime or gray cement). If in doubt, have the floor install a sample before grouting the entire surface.
- The grout should always be 1mm deeper than the tiles, not flush with the tiles. This is so that the shape of the tiles is still visible and the grout is less visible.

- Before starting grouting, wet the floor slightly. Grout small areas at a time and finish off nicely in time, this to avoid a cement slurry.
- Once the tiles are completely dry, rub them in twice with an impregnating agent (Funcosil AG).

**Funcosil AG Instructions:**

**Only apply the impregnating agent when the floor and joints are sufficiently dry (moisture content < 6%).**

1. Shake the bottles well before use.
  2. We always use a paint roller with nap and a wide brush.
  3. Pour the product into a container (a paint tray is the most practical).
  4. Use the brush for the edges, then apply the impregnating product evenly with the roller. Be careful not to apply too much at once to prevent flaking of the product.
  5. If only a brush is used, streaks may occur.
  6. Apply the impregnating agent both horizontally and vertically. Allow the first coat to dry before applying the second coat.
- Weekly maintenance with a vacuum cleaner, followed by cleaning with a nourishing soap (Lithofin Wash & Clean).
  - And now, enjoy the beautiful result!

