



MANOIR MARIE

ARTISANALE VLOEREN

## HANDICRAFT TERRACOTTA BROWN-GREY

### TECHNICAL DATA

- 2 available sizes:

17cm x 17cm x 2-2.5cm (ca 34 pcs/m<sup>2</sup>) [6.69 x 6.69 x 0.59-0.79 in]

with joint width of 2 (to 3) mm [0.08-0.12 in] (as narrow as possible)

22cm x 22cm x 2-2.5cm (ca 20.5 pcs/m<sup>2</sup>) [8.66 x 8.66 x 0.59-0.79 in]

with joint width of 2 (to 3) mm [0.08-0.12 in] (as narrow as possible)

This is a new handmade natural product of baked clay and hence the colour and size of the tiles within 1 batch and between several production batches may differ slightly.



~ Indoor & Covered ~

For interior use and covered terraces.

*This is a new unique handmade product that can only be manufactured in small volumes: please order in time!*

### INSTALLING INSTRUCTIONS

- It is of major importance that the tiles are well mixed.
- The tiles are generally laid in running bond.
- We recommend to keep a joint width of 2 (to 3) mm. The terracottas are handmade, may differ slightly in size and a good installation will require just a little more attention and time. The laying in running bond will help to keep the prescribed joint width. This procedure allows to obtain the most rural outcome with an appearance of the olden days.
- Wet the tiles briefly before installation so that the glue/ mortar cannot dry too quickly.
- To be laid in white mortar bed or thick glue of 1cm.
- It's appropriate to double-glue the tiles, this means put glue on both the tile and the underground.
- Joint colour: silver grey or old white. In case of doubt, you may ask the floor layer to perform a sample before jointing the whole surface.

- The joint can always be 1 mm deeper than the terracottas, so not level with them. This will keep the shape of the tiles visible whereas the joint remains less apparent.
- Before starting the jointing work, wet the floor abundantly. Joint small surfaces at once and sweep them off regularly. The tiles are very susceptible to cement grout film and must be cleaned correctly.
- When the tiles are completely dried out, clean the entire surface (with cement remover when necessary) until all traces of cement are removed. When the floor is fully dry again, please treat the surface with the impregnation product “Remmers Funcosil AG impregnering” or “Lithofin Cotto Pre Wax”. Apply the product twice with a soft painting roller, wet on wet. The product can foam slightly while you are applying it. After treating the whole floor, please polish it with a clean cotton cloth until all stripes have disappeared. Please only walk over the floor after 24 hours.
- Weekly maintenance with a vacuum cleaner and a nourishing soap (Berdy Topbril or Lithofin Wash & Clean) afterwards.
- Enjoy the beautiful result now!