MANOIR MARIE

ARTISANALE VLOEREN

OLD TERRACOTTA ROUGE ANTIQUE 10x10

TECHNICAL DATA

10 cm x 10 cm x 2 à 2,5cm thick

ca 90 pc/sqm with joint width 1mm (almost touching).

(ca 55 kg/m²)



This is an old recovered handmade product: sizes of the bricks may vary slightly from one to another. Color shade may also vary slightly from lot to lot. The rough side is the top, sawn side is the bottom.



For interior use and covered terraces.

This is an old recycled product: please order in time since the old recycled floor tiles are becoming scarce.

INSTALLING INSTRUCTIONS

- It is of major importance that the tiles are well mixed.
- The tiles are always laid in irregular bond. That means that entire, half and three-quarter tiles are being laid at random to one's own taste.
- We recommend to keep a joint width of 1 (to 2) mm. The tiles are handmade, may differ slightly in size and a good installation will require just a little more attention and time. The laying in irregular bond of the tiles will help to keep the prescribed joint width. This procedure allows to obtain the most authentic outcome with an appearance of the olden days.
- Wet the tiles briefly before installation so that mortar/glue cannot dry too quickly.
- To be laid in white mortar bed or in a thick glue of 1cm.
- It's appropriate to double-glue the tiles, this means put glue on both the tile and the underground.
- Joint colour: crème-beige (10L white sand - 20 L dune sand - 10L white cement - 0.5L yellow sulfur (Jasmine can also be used). In case of doubt, you may ask the floor layer to perform a sample before jointing the whole surface.

- The joint can always be 1 mm deeper than the tiles, so not level with them. This will keep the shape of the tiles visible whereas the joint remains less apparent.
- Before starting the jointing work, wet the floor abundantly. Joint small surfaces at once and sweep them off regularly. The tiles are very susceptible to cement grout film and must be cleaned correctly.
- Once the tiles are completely dry, rub them in twice with an impregnating agent (Funcosil AG).

Funcosil AG Instructions:

Only apply the impregnating agent when the floor and joints are sufficiently dry (moisture content < 6%).

1. Shake the bottles well before use.
2. We always use a paint roller with nap and a wide brush.
3. Pour the product into a container (a paint tray is the most practical).
4. Use the brush for the edges, then apply the impregnating product evenly with the roller. Be careful not to apply too much at once to prevent flaking of the product.
5. If only a brush is used, streaks may occur.
6. Apply the impregnating agent both horizontally and vertically. Allow the first coat to dry before applying the second coat.

- Weekly maintenance with a vacuum cleaner, followed by cleaning with a nourishing soap (Lithofin Wash & Clean).
- And now, enjoy the beautiful result!

